

XIRING Xi-Sign 4000 Quick Guide



XIRING Xi-Sign is a chip card reader that uses the cryptographic capabilities of EMV chip cards to offer secure authentication/authorization services in e-banking.

Using the reader

The card must be inserted into the reader as shown in the picture. Inserting the card automatically activates the reader and the screen will show the following options:

I	,	A		O	R				
M	E	N	U						

From that moment on, the reader is ready to execute the security operations as follows:

AUTHORIZATION

This operation can be activated directly by pressing I key or, as an alternative, by pressing MENU and selecting the IDENTIFIC. option and pressing OK. Its activation will be followed by the card's PIN request:

I N S E R T P I N

The PIN must be typed and followed by **OK**

The reader communicates with the card to verify the PIN and, if the value is correct, a confirmation message is displayed:

PIN OK

Finally, the operation's result is presented and can be used on the electronic channel that requested the authorization:

R E S P O N S E -

1 2 3 4 5 6

OTHER FUNCTIONS:

Besides the security operations, the reader implements the following functions, selectable through the **MENU**:

ROMANA/ENGLISH : Allows changing the message Language.

VERSION: Displays the reader's version identifier.

WARNING! Before using the device for the first time, the plastic battery foil insulation must be removed.